



Operation Manual

Goodrive100-01 Series Inverter Special for PV Water Pumps



Preface

Goodrive100-01 special inverters are developed for the power supply of water pumps based on the core control algorithm of Goodrive high performance inverters and the control requirements of PV water pumps. All series products apply Infineon power modules. The function of Maximum power tracking, dormant at weak light, wake up at strong light, high water level dormant, underload pre-warning and other control protection functions can ensure normal operation of water pumps according to the customers' requirements to switch to the grid power supply.

Please refer to this manual and the manual of Goodrive100 to commission the inverter.

If the product is ultimately used for military affairs or manufacture of weapon, it will be listed on the export control formulated by **Foreign Trade Law of the People's Republic of China**. Rigorous review and necessary export formalities are needed when exported.

Our company reserves the right to update the information of our products.

Contents

| | |
|---|----|
| Preface..... | 1 |
| Contents..... | 2 |
| 1 Product overview | 3 |
| 1.1 Product specifications..... | 3 |
| 1.2 Name plate | 5 |
| 1.3 Model instruction..... | 5 |
| 1.4 Rated specifications | 6 |
| 1.5 Terminals, wiring and dimension diagram | 7 |
| 1.5.1 Wiring diagram of the control circuit..... | 7 |
| 1.5.2 Terminals arrangement | 7 |
| 1.5.3 Terminals description | 7 |
| 1.5.4 Dimension drawings | 9 |
| 2 Function parameters | 10 |
| 2.1 Parameters of common functions..... | 10 |
| 2.2 Parameters of special functions | 24 |
| 3 Commissioning guide..... | 32 |
| 3.1 Wiring and commissioning steps..... | 32 |
| 3.1.1 Commissioning steps during power supply | 32 |
| 3.1.2 Commissioning steps during grid power supply..... | 34 |
| 4 Fault instruction | 36 |
| 4.1 Common faults and solutions | 36 |

1 Product overview


1.1 Product specifications

| Functions | | Specifications |
|---------------------|---|--|
| Input | Input AC voltage (V) | AC 3PH 380V (-15%) ~440V (+10%) |
| | Maximum input DC bus voltage | 800VDC |
| | Recommended DC bus voltage | 513VDC |
| | Recommended MPP range | 350~750VDC |
| | Input current (A) | Refer to the rated value |
| | Input frequency (Hz) | 50Hz or 60Hz Allowed range: 47~63Hz |
| Output | Output voltage (V) | 0~ the input voltage |
| | Output current (A) | Refer to the rated value |
| | Output power (kW) | Refer to the rated value |
| | Output frequency (Hz) | 0~400Hz |
| Control | Control mode | SVPWM, SVC |
| | Motor type | Asynchronous motor |
| | Speed ratio | Asynchronous motor 1:100 (SVC) |
| | Speed control accuracy | ±0.2%(SVC) |
| | Speed fluctuation | ± 0.3%(SVC) |
| | Torque response | <20ms(SVC) |
| | Torque control accuracy | 10%(SVC) |
| | Starting torque | 0.25Hz/150%(SVC) |
| Overload capability | 150% of rated current: 1 minute 180% of rated current: 10 seconds 200% of rated current: 1 second | |

| Functions | | Specifications |
|----------------------|--------------------------------------|--|
| Running control | Frequency setting method | Digital setting, analog setting, pulse frequency setting, multi-step speed running setting, simple PLC setting, PID setting, MODBUS communication setting Shift between the set combination and set channel. |
| | Auto-adjustment of the voltage | Keep a stable voltage automatically when the grid voltage transients |
| | Fault protection | Provide over 30 fault protection functions: overcurrent, overvoltage, undervoltage, overheating, phase loss and overload, etc. |
| | Special functions for PV water pumps | Maximum power tracking, pre-warning at weak light (A-LS), auto wake up at strong light, pre-warning when full water (A-tF), auto wake up at low water level, underload pre-warning (A-LL) and fault protection of water level sensor (tSF), when pre-warning, the inverter is in stand-by. |
| Peripheral interface | Terminal analog input resolution | $\leq 20\text{mV}$ |
| | Terminal switch input resolution | $\leq 2\text{ms}$ |
| | Analog input | 1 (AI2) 0~10V/0~20mA and 1 (AI3) -10~10V |
| | Analog output | 2 (AO1, AO2) 0~10V /0~20mA |
| | Digital input | 4 common inputs, the Max. frequency: 1kHz, internal impedance: 3.3k Ω ; 1 high speed input, the Max. frequency: 50kHz |
| | Relay output | 2 programmable relay output RO1A NO, RO1B NC, RO1C common terminal RO2A NO, RO2B NC, RO2C common terminal |

| Functions | | Specifications |
|-----------|--|--|
| | | Contactors capability: 3A/AC250V |
| Others | Keypad | External (can be 30m) |
| | Mountable mode | Wall mountable and flange mountable |
| | Temperature of the running environment | -10~50°C, derate above 40°C |
| | Average non-fault time | 2 years (25°C ambient temperature) |
| | Protective degree | IP20 |
| | Cooling | Air-cooling |
| | Braking unit | Embedded |
| | EMC filter | Built-in C3 filter: meet the degree requirement of IEC61800-3 C3 Optional external filter: meet the degree requirement of IEC61800-3 C2 |

1.2 Name plate



Note: Above is an example of name plates of Goodrive100-01 standard products.

CE/TUV/IP20 will be marked on the name plate according to actual certifications.

1.3 Model instruction

The model instruction contains information on the inverter. The user can find the model code on the type designation label attached to the inverter or the simple name plate.

GD100-01 - 5R5G - 4

①

②

③

| Field identification | Sign | Detailed description of the sign | Detailed content |
|----------------------|------|----------------------------------|---|
| | | | |
| Product abbreviation | ① | Product abbreviation | Goodrive100-01 is abbreviated as GD100-01 Goodrive100-01: special for PV water pumps |
| Rated power | ② | Power range + Load type | 5R5-5.5kW G—Constant torque load |
| Voltage degree | ③ | Voltage degree | 4: AC 3PH 380V (-15%)~440V(+10%) |


1.4 Rated specifications

| GD100-01-XXXX-4 | 0R7G | 1R5G | 2R2G | 004G | 5R5G | 7R5G | 011G | 015G |
|------------------------------|------|------|------|------|------|------|------|------|
| Rated output power(kW) | 0.75 | 1.5 | 2.2 | 4 | 5.5 | 7.5 | 11 | 15 |
| Maximum DC input current (A) | 4.2 | 6.1 | 7.1 | 16.5 | 23.9 | 30.6 | 39.2 | 49.0 |
| Rated input current(A) | 3.4 | 5.0 | 5.8 | 13.5 | 19.5 | 25 | 32 | 40 |
| Rated output current(A) | 2.5 | 3.7 | 5 | 9.5 | 14 | 18.5 | 25 | 32 |


Note: the output current is the rated value when the output voltage is 380V. If the output voltage is 400V, 415V and 440V, the output current can be calculated.

1.5 Terminals, wiring and dimension diagram

1.5.1 Wiring diagram of the control circuit



1.5.2 Terminals arrangement



1.5.3 Terminals description


| Terminal name | Description |
|---------------|--|
| RO1A | RO1 relay output, RO1A NO, RO1B NC, RO1C common terminal |
| RO1B | Contactor capability:3A/AC250V, 1A/DC30V |

| Terminal name | Description | |
|---------------|---|--|
| RO1C | | |
| RO2A | RO2 relay output, RO2A NO, RO2B NC, RO2C common terminal Contactor capability:3A/AC250V | |
| RO2B | | |
| RO2C | | |
| +10V | Local power supply +10V | |
| AI2 | 1. Input range: AI2 voltage and current can be chose: 0~10V/0~20mA; AI3 can be shifted by J3 , -10V~+10V 2. Input impedance: voltage input: 20k Ω ; current input: 500 Ω 3. Resolution: the minimum one is 5mV when 10V corresponds to 50Hz 4. Deviation $\pm 1\%$, 25 $^{\circ}\text{C}$ | |
| AI3 | | |
| GND | +10V reference null potential | |
| AO1 | 1. Output range:0~10V or 0~20mA 2. The voltage or the current output is depended on the jumper 3. Deviation $\pm 1\%$,25 $^{\circ}\text{C}$ | |
| AO2 | | |
| PE | Grounding terminal | |
| PW | Provide the input switch working power supply from external to internal. Voltage range: 12~24V | |
| 24V | The inverter provides the power supply for users with a maximum output current of 200mA | |
| COM | +24V common terminal | |
| S1 | Switch input 1 | 1. Internal impedance:3.3k Ω 2. 12~30V voltage input is available 3. The terminal is the dual-direction input terminal supporting both NPN and PNP 4. Max input frequency:1kHz 5. All are programmable digital input terminal. User can set the terminal function through function codes. |
| S2 | Switch input 2 | |
| S3 | Switch input 3 | |
| S4 | Switch input 4 | |
| HDI | Except for S1~S4, this terminal can be used as high frequency input | |

| Terminal name | Description |
|---------------|--|
| | channel. Max. input frequency:50kHz |
| 485+ | 485 communication interface and 485 differential signal interface |
| 485- | If it is the standard 485 communication interface, please use twisted pairs or shield cable. |

1.5.4 Dimension drawings

Wall installation



| Power | W1 | W2 | H1 | H2 | D1 | Installation hole |
|--------------|-------|-------|-------|-------|-------|-------------------|
| 0.75kW~2.2kW | 126.0 | 115.0 | 186.0 | 175.0 | 155.0 | 5 |
| 4kW~5.5kW | 146.0 | 131.0 | 256.0 | 243.5 | 167.0 | 6 |
| 7.5kW~15kW | 170.0 | 151.0 | 320.0 | 303.5 | 196.3 | 6 |

2 Function parameters

For the convenience of function codes setting, the function group number corresponds to the first level menu, the function code corresponds to the second level menu and the function code corresponds to the third level menu.

1. Below is the instruction of the function lists:

The first column "Function code": codes of function parameter group and parameters;

The second column "Name": full name of function parameters;

The third column "Detailed illustration of parameters": detailed illustration of the function parameters;

The fourth column "Default": original factory settings of the parameters;

The fifth column "Modify": the modifying character of function codes (the parameters can be modified or not and the modifying conditions), below is the instruction:

"○": means the set value of the parameter can be modified on stop and running state;

"⊙": means the set value of the parameter can not be modified on the running state;

"●": means the value of the parameter is the real detection value which can not be modified;

"◆": means the function code is hidden.

(In order to avoid mistakes, the modify attribute of each parameter is limited by the inverter)

2.1 Parameters of common functions

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------------------------------|--------------------|--|---------|--------|
| P00 Group Basic function group | | | | |
| P00.00 | Speed control mode | 0: SVC 0 No need to install encoders. Suitable in applications which need low frequency, big torque for high accuracy of rotating speed and torque control. Relative to mode 1, it is more suitable for the applications which need small | 2 | ⊙ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|---------------------|---|---------|--------|
| | | <p>power.</p> <p>1: SVC 1</p> <p>1 is suitable in high performance cases with the advantage of high accuracy of rotating speed and torque. It does not need to install pulse encoder.</p> <p>2:SVPWM control</p> <p>2 is suitable in applications which do not need high control accuracy, such as the load of fan and pump. One inverter can drive multiple motors.</p> | | |
| P00.01 | Run command channel | <p>Select the run command channel of the inverter. The control command of the inverter includes: start, stop, forward/reverse rotating, jogging and fault reset.</p> <p>0:Keypad running command channel("LOCAL/REMOT" light off)</p> <p>Carry out the command control by RUN, STOP/RST on the keypad.</p> <p>Set the multi-function key QUICK/JOG to FWD/REVC shifting function (P07.02=3) to change the running direction; press RUN and STOP/RST simultaneously in running state to make the inverter coast to stop.</p> <p>1:Terminal running command channel ("LOCAL/REMOT" flickering)</p> <p>Carry out the running command control by the forward rotation, reverse rotation and forward</p> | 0 | ○ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|--------------------------------------|---|-----------|--------|
| | | jogging and reverse jogging of the multi-function terminals 2:Communication running command channel ("LOCAL/REMOTE" on); The running command is controlled by the upper monitor via communication | | |
| P00.03 | Max. output frequency | This parameter is used to set the maximum output frequency of the inverter. Users need to pay attention to this parameter because it is the foundation of the frequency setting and the speed of acceleration and deceleration. Setting range: P00.04~400.00Hz | 50.00 Hz | ⊙ |
| P00.04 | Upper limit of the running frequency | The upper limit of the running frequency is the upper limit of the output frequency of the inverter which is lower than or equal to the maximum frequency. Setting range:P00.05~P00.03 (Max. output frequency) | 50.00 Hz | ⊙ |
| P00.05 | Lower limit of the running frequency | The lower limit of the running frequency is that of the output frequency of the inverter. The inverter runs at the lower limit frequency if the set frequency is lower than the lower limit. Note: Max. output frequency \geq Upper limit frequency \geq Lower limit frequency Setting range:0.00Hz~P00.04 (Upper limit of the running frequency) | 0.00Hz | ⊙ |
| P00.11 | ACC time 1 | ACC time means the time needed if the inverter speeds up from 0Hz to the Max. output | Depend on | ○ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|-----------------------------|---|-----------------|--------|
| | | frequency (P00.03). | model | |
| P00.12 | DEC time 1 | <p>DEC time means the time needed if the inverter speeds down from the Max. Output frequency to 0Hz (P00.03).</p> <p>Goodrive100 series inverters have four groups of ACC/DEC time which can be selected by P05. The factory default ACC/DEC time of the inverter is the first group.</p> <p>Setting range of P00.11 and P00.12:0.0~3600.0s</p> | Depend on model | ○ |
| P00.13 | Running direction selection | <p>0: Runs at the default direction, the inverter runs in the forward direction. FWD/REV indicator is off.</p> <p>1: Runs at the opposite direction, the inverter runs in the reverse direction. FWD/REV indicator is on.</p> <p>Modify the function code to shift the rotation direction of the motor. This effect equals to the shifting the rotation direction by adjusting either two of the motor lines (U, V and W). The motor rotation direction can be changed by QUICK/JOG on the keypad. Refer to parameter P07.02.</p> <p>Note: When the function parameter comes back to the default value, the motor's running direction will come back to the factory default state, too. In some cases it should be used with caution after commissioning if the change of</p> | 0 | ○ |


| Function code | Name | Detailed illustration of parameters | Default | Modify |
|--|----------------------------|--|---------|--------|
| | | <p>rotation direction is disabled. Reverse rotation is forbidden for water pump applications and the function code can not be adjusted.</p> <p>2: Forbid to run in reverse direction: It can be used in some special cases if the reverse running is disabled.</p> | | |
| P00.15 | Motor parameter autotuning | <p>0:No operation</p> <p>1:Rotation autotuning Comprehensive motor parameter autotune. It is recommended to use rotation autotuning when high control accuracy is needed.</p> <p>2:Static autotuning It is suitable in the cases when the motor can not de-couple form the load. The autotuning for the motor parameter will impact the control accuracy.</p> <p>3: Static autotuning 2 (No autotuning for non-load current and mutual inductance)</p> | 0 | ⊙ |
| P00.18 | Function restore parameter | <p>0:No operation</p> <p>1:Restore the default value</p> <p>2:Clear fault records</p> <p>Note: The function code will restore to 0 after finishing the operation of the selected function code.</p> <p>Restoring to the default value will cancel the user password, please use this function with caution.</p> | 0 | ⊙ |
| P01 Group Start-up and stop control | | | | |

| Function code | Name | Detailed illustration of parameters | Default | Modify | |
|-------------------------------------|---------------------------------------|--|--|-----------------|---|
| P01.08 | Stop mode | 0: Decelerate to stop: after the stop command becomes valid, the inverter decelerates to reduce the output frequency during the set time. When the frequency decreases to 0Hz, the inverter stops. 1: Coast to stop: after the stop command becomes valid, the inverter ceases the output immediately. And the load coasts to stop at the mechanical inertia. | 1 | ○ | |
| P01.18 | Operation protection | 0: The terminal running command is invalid when powering on. 1: The terminal running command is valid when powering on. | 0 | ○ | |
| P01.21 | Restart after power off | 0: Disabled 1: Enabled, | 0 | ○ | |
| P02 Group Motor 1 parameters | | | | | |
| P02.01 | Rated power of asynchronous motor | 0.1~3000.0kW | Set the parameter of the asynchronous motor. In order to ensure the controlling performance, set the P02.01~P02.05 according to the name plate of the asynchronous motor. | Depend on model | ⊙ |
| P02.02 | Rated frequency of asynchronous motor | 0.01Hz~P00.03 | | 50.00 Hz | ⊙ |
| P02.03 | Rated speed of | 1~36000rpm | Goodrive100 series | Depend on | ⊙ |

| Function code | Name | Detailed illustration of parameters | | Default | Modify |
|---------------|---------------------------------------|-------------------------------------|---|-----------------|--------|
| | asynchronous motor | | inverters provide the function of parameter | model | |
| P02.04 | Rated voltage of asynchronous motor | 0~1200V | autotuning. Correct parameter autotuning comes from the correct setting of the | Depend on model | ⊙ |
| P02.05 | Rated current of asynchronous motor | 0.8~6000.0A | motor name plate. In order to ensure the controlling performance, please configure the motor according to the standard principles, if the gap between the motor and the standard one is huge, the features of the inverter will decrease. Note: Reset the rated power of the motor (P02.01), initialize the motor parameter of P02.02~P02.10. | Depend on model | ⊙ |
| P02.06 | Stator resistor of asynchronous motor | 0.001~65.535Ω | After finish the motor parameter autotuning, the set value of | Depend on model | ○ |

| Function code | Name | Detailed illustration of parameters | | Default | Modify |
|--------------------------------|--|---|---|-----------------|----------------------------------|
| P02.07 | Rotor resistor of asynchronous motor | 0.001~65.535Ω | P02.06~P02.10 will renew automatically. These parameters are basic parameters controlled by vectors which directly impact the features. Note: Users cannot modify the parameters freely. | Depend on model | <input type="radio"/> |
| P02.08 | Leakage inductance of asynchronous motor | 0.1~6553.5mH | | Depend on model | <input type="radio"/> |
| P02.09 | Mutual inductance of asynchronous motor | 0.1~6553.5mH | | Depend on model | <input type="radio"/> |
| P02.10 | Non-load current of asynchronous motor | 0.1~6553.5A | | Depend on model | <input type="radio"/> |
| P04 Group SVPWM control | | | | | |
| P04.00 | V/F curve setting | These function codes define the V/F curve of Goodrive100 motor 1 to meet the need of different loads. 0: Straight line V/F curve; applying to the constant torque load 1: Multi-dots V/F curve 2: 1.3th power low torque V/F curve 3: 1.7th power low torque V/F curve 4: 2.0th power low torque V/F curve | | 4 | <input checked="" type="radio"/> |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|--------------------|--|---------|-----------------------|
| | | <p>Curves 2~4 apply to the torque loads such as fans and water pumps. Users can adjust according to the features of the loads to get the best performance.</p> <p>5: Customized V/F (V/F separation); in this mode, V can be separated from f and f can be adjusted through the frequency given channel set by P00.06 or the voltage given channel set by P04.27 to change the feature of the curve.</p> <p>Note: V_b in the below picture is the motor rated voltage and f_b is the motor rated frequency.</p> | | |
| P04.01 | Torque boost | Torque boost to the output voltage for the features of low frequency torque. P04.01 is for the Max. output voltage V_b . | 0.0% | <input type="radio"/> |
| P04.02 | Torque boost close | <p>P04.02 defines the percentage of closing frequency of manual torque to f_b.</p> <p>Torque boost should be selected according to the load. The bigger the load is, the bigger the torque is. Too big torque boost is inappropriate because the motor will run with over magnetic, and the current of the inverter will increase to add the temperature of the inverter and decrease the efficiency.</p> | 20.0% | <input type="radio"/> |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|----------------------------------|----------------------------|---|---------|--------|
| | | <p>When the torque boost is set to 0.0%, the inverter is automatic torque boost.</p> <p>Torque boost threshold: below this frequency point, the torque boost is valid, but over this frequency point, the torque boost is invalid.</p>  <p>The setting range of P04.01:0.0%:(automatic) 0.1%~10.0%</p> <p>The setting range of P04.02:0.0%~50.0%</p> | | |
| P04.09 | V/F slip compensation gain | <p>This function code is used to compensate the change of the rotation speed caused by load during compensation SVPWM control to improve the rigidity of the motor. It can be set to the rated slip frequency of the motor which is counted as below:</p> $\Delta f = f_b - n \cdot p / 60$ <p>Of which, f_b is the rated frequency of the motor, its function code is P02.01; n is the rated rotating speed of the motor and its function code is P02.02; p is the pole pair of the motor.</p> <p>100.0% corresponds to the rated slip frequency Δf.</p> <p>Setting range:0.0~200.0%</p> | 0.0% | ○ |
| P05 Group Input terminals | | | | |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|---|--|---------|--------|
| P05.00 | HDI input selection | 0: HDI is high pulse input. See P05.49~P05.54 1:HDI is switch input | 0 | ⊙ |
| P05.01 | S1 terminals function selection | 0: No function 1: Forward rotation operation 2: Reverse rotation operation 3: 3-wire control operation 4: Forward jogging 5: Reverse jogging 6: Coast to stop 7: Fault reset 8: Operation pause 9: External fault input 42: PV disabled 43: PV voltage reference (optional for grid power supply) 44: Switch between solar input and power frequency input 45~63: Reserved | 1 | ⊙ |
| P05.02 | S2 terminals function selection | | 4 | ⊙ |
| P05.03 | S3 terminals function selection | | 7 | ⊙ |
| P05.04 | S4 terminals function selection | | 0 | ⊙ |
| P05.09 | HDI terminals function selection | | 0 | ⊙ |
| P05.10 | Polarity selection of the input terminals | 0x000~0x10F | 0X000 | ⊙ |
| P05.49 | HDI high-speed | The function selection when HDI terminals is high-speed pulse input | 0 | ⊙ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|-----------------------------------|---|---|-----------|--------|
| | pulse input function | 0:Frequency setting input, frequency setting source 1:Counter input, high-speed pulse counter input terminals 2:Length counting input, length counter input terminals | | |
| P05.50 | Lower limit frequency of HDI | 0.00kHz~P05.52 | 0.00 kHz | ○ |
| P05.51 | Corresponding setting of HDI low frequency setting | -100.0%~100.0% | 0.0% | ○ |
| P05.52 | Upper limit frequency of HDI | P05.50~50.00kHz | 50.00 kHz | ○ |
| P05.53 | Corresponding setting of upper limit frequency of HDI | -100.0%~100.0% | 100.0 % | ○ |
| P05.54 | HDI frequency input filter time | 0.000s~10.000s | 0.100s | ○ |
| P06 Group Output terminals | | | | |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|----------------------------------|---|---------|--------|
| P06.03 | Relay RO1 output selection | 0:Invalid 1:In operation 2:Forward rotation operation 3:Reverse rotation operation 4: Jogging operation 5:The inverter fault 6:Frequency degree test FDT1 7:Frequency degree test FDT2 8:Frequency arrival 9:Zero speed running 10:Upper limit frequency arrival 11:Lower limit frequency arrival 12:Ready for operation 13:Pre-magnetizing | 1 | ○ |
| P06.04 | Relay RO2 output selection | 14:Overload pre-alarm 15: Underload pre-alarm 16:Completion of simple PLC stage 17:Completion of simple PLC cycle 18:Setting count value arrival 19:Defined count value arrival 20:External fault valid 21: Reserved 22:Running time arrival 23:MODBUS communication virtual terminals output 24~26: Reserved 27: Weak light 28:Switch between solar input and power | 5 | ○ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|-------------------------------------|-------------------------------|---|---------|----------------------------------|
| | | frequency input after threshold arrived 29:Switch between solar input and power frequency input by terminal input 30 :Reserved | | |
| P06.10 | Switch on delay of RO1 | 0.000~50.000s | 0.000s | <input type="radio"/> |
| P06.11 | Switch off delay of RO1 | 0.000~50.000s | 0.000s | <input type="radio"/> |
| P06.12 | Switch on delay of RO2 | 0.000~50.000s | 0.000s | <input type="radio"/> |
| P06.13 | Switch off delay of RO2 | 0.000~50.000s | 0.000s | <input type="radio"/> |
| P08 Group Enhanced functions | | | | |
| P08.28 | Times of fault reset | 0~10 | 0 | <input type="radio"/> |
| P08.41 | Overmodulation selection | 0x00~0x11 LED ones 0: Invalid 1: Valid LED tens 0: Light overcommission; 1: Heavy overcommission | 01 | <input checked="" type="radio"/> |

2.2 Parameters of special functions

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---|---|--|-----------|--------|
| P11 Group Protective parameters | | | | |
| P11.01 | Frequency-decreasing at sudden power loss | 0.00~1.00 (If the voltage degree is 400V, 0.85 corresponds to 460V) | 0.85 | ⊙ |
| P11.02 | Frequency decreasing ratio at sudden power loss | 0.00Hz~P00.03/s Setting range: 0.00Hz/s~P00.03 (the Max. frequency) After the power loss of the grid, the bus voltage drops to the sudden frequency-decreasing point, the inverter begin to decrease the running frequency at P11.02, to make the inverter generate power again. The returning power can maintain the bus voltage to ensure a rated running of the inverter until the recovery of power. | 2.00 Hz/s | ○ |
| P15 Group Special functions for PV inverters | | | | |
| P15.00 | PV inverter selection | 0: Invalid 1: Enable 0 means the function is invalid and the group of parameters can not be used 1 means the function is enabled, and P15 parameters can be adjusted | 0 | ⊙ |
| P15.01 | Vmpp voltage reference | 0: Voltage reference 1: Max. power tracking 0 means to apply voltage reference mode. The reference is a fixed value and given by P15.02. 1 means to apply the reference voltage of Max. | 1 | ⊙ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|-------------------------------|---|---------|--------|
| | | <p>power tracking. The voltage is changing until the system is stable.</p> <p>No matter what kind of reference voltage is applied, if the bus voltage is higher than reference voltage, the target frequency will change to the upper limit of PI output frequency and if the bus voltage is lower than the reference voltage, the target frequency will change to the lower limit of PI output frequency.</p> <p>Note: If terminal 43 is valid, the function is invalid.</p> | | |
| P15.02 | Vmpp voltage keypad reference | <p>0.0~6553.5Vdc</p> <p>If P15.01 is 0, the reference voltage is given by P15.02.</p> | 530.0V | ○ |
| P15.03 | PI control deviation | <p>0.0~100.0% (100.0% corresponds to P15.02)</p> <p>If the ratio percentage of bus voltage to reference voltage, which is $\text{abs}(\text{bus voltage}-\text{reference voltage}) \times 100.0\% / \text{reference voltage}$, if the value exceeds the deviation limit of P15.03, PI adjustment is available, otherwise, there is no PI adjustment and the value is defaulted to be 0.0%</p> <p>Abs: the absolute value</p> | 0.0% | ○ |
| P15.04 | Upper frequency of PI output | <p>P15.05~100.0%(100.0% corresponds to P00.03)</p> <p>P15.04 is used to limit the Max. value of target frequency, 100.0% corresponds to P00.03.</p> <p>After PI adjustment, the target frequency can not exceed the upper limit.</p> | 100.0% | ○ |
| P15.05 | Lower frequency | <p>0.0%~P15.04(100.0% corresponds to P00.03)</p> <p>P15.05 is used to limit the Min. value of target</p> | 20.0% | ○ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|---------------------|--|---------|--------|
| | of PI output | frequency, 100.0% corresponds to P00.03. After PI adjustment, the target frequency can not exceed the lower limit. | | |
| P15.06 | KP1 | 0.00~100.00 The proportion coefficient 1 of the target frequency The bigger the value is, the stronger the effect and faster the adjustment is. | 1.00 | ○ |
| P15.07 | KI1 | 0.00~100.00 The integral coefficient 1 of the target frequency The bigger the value is, the stronger the effect and faster the adjustment is. | 1.00 | ○ |
| P15.08 | KP2 | 0.00~100.00 The proportion coefficient 2 of the target frequency The bigger the value is, the stronger the effect and faster the adjustment is. | 4.00 | ○ |
| P15.09 | KI2 | 0.00~100.00 The integral coefficient 2 of the target frequency The bigger the value is, the stronger the effect and faster the adjustment is. | 4.00 | ○ |
| P15.10 | PI switching point | 0.0~6553.5Vdc If the absolute value of bus voltage minus the reference value is bigger than P15.10, it will switch to P15.08 and P15.09; otherwise it is P15.06 and P15.07. | 50.0V | ◎ |
| P15.11 | Water level control | 0: Invalid 1: AI1 2: AI2 3: AI3 | 0 | ◎ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|------------------------|--|---------|--------|
| | | The function is invalid if select 0. 1~3 is the reference from the simulating signal source of water level control. After selecting the simulating signal source, P15.12, P15.13, P15.14 and P15.15 are valid. | | |
| P15.12 | Water level threshold | 0.0~100.0% If the simulating signal is less than the water level threshold and keep in the state after the delay time set by P15.13, report A-tF and dormant. If the time is not reached, the signal is bigger than the water level threshold; the time will be cleared automatically. When the signal time is shorter than the water level threshold time, the time will be counted again. | 25.0% | ○ |
| P15.13 | Full water delay | 0~10000s Time setting of full water delay | 60s | ○ |
| P15.14 | Non-water delay | 0~10000s Time setting of non-water delay. In the full water pre-warning, if the detected simulating signal is bigger than the value set by P15.12, it begins to count the delay time. After lasting for the time set by P15.14, the pre-warning will be cleared. Under the condition of non continuous, delay time will be reset automatically. | 600s | ○ |
| P15.15 | Hydraulic probe damage | 0.0~100.0% 0.0%: Invalid. If it is not 0.0%, when the signal is longer than P15.15, it will report tSF fault directly and stop. | 0.0% | ○ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|--|---|---------|--------|
| P15.16 | Operation time of water pump underload | 0.0~1000.0s Set the operation time of underload operation. Under the continuous underload operation, it will report A - LL if the operation time is reached. | 60.0s | ○ |
| P15.17 | Current detection of underload operation | 0.0%: Automatic detection 0.1~100.0% If not 0.0%, it is determined by the inverter. If it is not 0.0%, it is determined by P15.17. 100.0% corresponds to the rated motor current. If the target frequency and the absolute value of the ramp frequency is less than or equal to P15.19, and the current is less than P15.17, after the time set by P15.16, it will report underload fault; otherwise, it will operate normally. If the state is not continuous, the delay counting will be cleared automatically. | 0.0% | ○ |
| P15.18 | Underload reset delay | 0.0~1000.0s Underload reset delay The operation time and reset time are counted at the same time during underload, and it is bigger than P15.16 generally to ensure underload pre-warning will be reported. After the time set by P15.18-P15.16, it will reset. If the value is the same as P15.16, it will reset when report underload pre-warning. | 120.0s | ○ |
| P15.19 | Lag frequency threshold | 0.00~200.00Hz P15.19 is the lag frequency for the analysis of underload operation. If the target frequency and the absolute value of the ramp frequency is less than or | 0.30Hz | ◎ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|---|--|---------|--------|
| | | equal to P15.19, the current will be compared. | | |
| P15.20 | Delay time of weak light | 0.0~3600.0s Delay time of weak light If the output frequency is less than or equal to the lower limit of PI output frequency and the state lasts for the set value, it will report A-LS and dormant. If the state is not continuous, the delay counting will be cleared automatically. Note: If the bus voltage is lower than +50.0V, it will report directly and no need to wait for the set time. | 100.0s | ○ |
| P15.21 | Delay time of wake-up at weak light | 0.0~3600.0s Delay time of wake-up at weak light After the delay time, the pre-warning time of weak light will be cleared and operate again. | 300.0s | ○ |
| P15.22 | Initial reference voltage display | 0.0~2000.0V | 0 | ● |
| P15.23 | Mini voltage reference of Max. power tracking | 0.0~P15.24 Valid in MPPT Max. tracking voltage, the Mini. tracked voltage Track in the range of P15.23~P15.24. P15.24 needs to be bigger than P15.23. The less the difference, the faster the tracking is. But the Max. voltage needs to be in the range. P15.23 and P15.24 can be adjusted according to site operation. | 450.0V | ○ |
| P15.24 | Max. voltage | P15.23~P15.28 Valid in MPPT Max. tracking voltage, the Max. | 550.0V | ○ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|---|---|---------|--------|
| | reference of Max. power tracking | tracked voltage | | |
| P15.25 | Adjustment of initial reference voltage | 0.0~200.0V MPPT begins to change from the reference voltage Initial reference voltage =Bus voltage-P15.25 | 2.0V | ○ |
| P15.26 | Upper and lower limit time of Vmppt | 0.0~10.0s When P15.26 is set to 0.0, the automatic adjustment is invalid. If it is not 0.0, the upper and lower limit of Vmppt will be adjusted automatically after the time set by P15.26. The medium value is the current bus voltage and the limit is P15.27: Maximum / Minimum reference voltage=Current bus voltage±P15.27 and it will update to P15.23 and P15.24 at the same time | 0.0s | ○ |
| P15.27 | Upper and lower limit of Vmppt | 20.0~100.0V The adjustment of the upper and lower limit | 30.0V | ○ |
| P15.28 | Maximum value of Vmppt | P15.24~6553.5V The upper limit can not exceed the P15.28 when Vmppt is the maximum value | 570.0V | ○ |
| P15.29 | Voltage samole of the solar output | 0:Invalid 1:AI1 2:AI2 3:AI3 No sample input when the selection is 0 | 0 | ◎ |
| P15.30 | Switch to | 0.0%~P15.31 | 5.0% | ○ |

| Function code | Name | Detailed illustration of parameters | Default | Modify |
|---------------|--|--|---------|--------|
| | the threshold of power frequency input | If the value is lower than the threshold, it can switch to power frequency input through the relay output If the value is 0.0%, it is invalid 100.0% corresponds to 10V or 20mA | | |
| P15.31 | Switch to the threshold of solar input | P15.30~100.0% If the value is higher than the threshold, it can switch to solar input through the relay output. In order to avoid repeated switching, the thresholds needs to be higher than the threshold of P15.30. If the value is 0.0%, it is invalid 100.0% corresponds to 10V or 20mA | 10.0% | ○ |
| P15.32 | Reserved | | | ○ |
| P15.33 | Reserved | | | ○ |

Remark:

- 1. The time when the inverters operated to the lower limit of PI output frequency after starting is determined by the ACC time.**
- 2. The instruction of delay time. If various delay conditions such as weak light, full water, and underload are met, the inverter will count the delay time respectively. After the separated delay time is arrived, it will report pre-warning and others are still kept. If the pre-warning is restored, but other conditions for delay are still existent, it will count after the precious time. So if the some pre-warning condition is not met, the pre-warning time will be cleared.**


3 Commissioning guide

3.1 Wiring and commissioning steps

3.1.1 Commissioning steps during power supply

1. Wire according to the diagram and check the wiring is correct or not and then switch on

Q2.



2. Set the motor parameters

(a) Set P00.18=1 and restore to the factory settings.

(b) Set P00.01=0 and change the command to keypad control.

(c) Set the name plate of the motor, including P02.01, P02.02, P02.03, P02.04 and P02.05 (remember to press "ENT" after setting).

3. Detection of water yield for water pumps

Set the lower limit of output frequency P00.05=6.00Hz, stop mode P01.08=1 and coast to

stop.

And then, set P15.00=1 to enable the special functions for water pumps, click "Run" key and the default mode is MPPT, observe the running frequency and water yield. If the operation frequency or water yield is low at normal light, the motor wires may be reserved, so it is necessary to exchange the wiring.

4. PI adjustment to the water yield

If the user requires large or low water yield, it is necessary to adjust PI (P15.06~P15.10) properly. The bigger PI parameters, the stronger the effect is, but the frequency fluctuation of the motor is bigger; in reserve, the lower the water yield is, the more stable the motor frequency is.

5. Commissioning of MPPT speed tracking

P15.23 and P15.24 is the minimum and maximum voltage of the power tracking in MPPT mode. If the voltage range is smaller, the faster the tracking is. But the bus voltage in normal operation needs to be in the range; otherwise the maximum power can not be tracked. Generally:

(a) If the rated motor voltage is 415V, P15.23=520(minimum reference voltage), P15.24=600(maximum reference voltage).

(b) If the rated motor voltage is 380V, P15.23=500(minimum reference voltage), P15.24=550(maximum reference voltage).

(c) If the rated motor voltage is 220V, P15.23=270(minimum reference voltage), P15.24=330(maximum reference voltage).

Above settings are only for reference and can be adjusted according to the actual applications or by automatic adjustment. P15.26 is used to adjust the time between the maximum voltage and minimum voltage of MPPT and can be used with P15.27 to adjust the maximum and minimum reference voltage. The upper limit of maximum reference voltage can not exceed the maximum setting value of P15.28.

6. Fault setting and reset time setting of fault delay

If the pre-warning of weak light, full water and underload are needed, it is necessary to set the detection point, delay time and reset time according to the actual working. Full water/no water settings are P15.11~P15.14; the function settings of underload are P15.16~P15.19; the function settings of weak light are P15.20~P15.21. Default settings

can be used, too.


7. Parameters setting after normal operation

If the water yield is normal and the system operation is stable, the commissioning is finished. Set P00.01=1, switch to terminal mode and set P01.18=1, P01.21=1 and P08.28=5.

Note: 0.85 of P11.01 corresponds to 460V. The coefficient can be modified, but can not be modified to below 0.41 (0.41 corresponds to undervoltage point 220V, so it may report undervoltage fault if the actual bus voltage is less than the value).

3.1.2 Commissioning steps during grid power supply

1. Wire according to the diagram and check the wiring is correct or not



Switch off Q2 and then switch on Q1.

2. After the power frequency, commission the system according to steps 2, 3, 4, 6 and 7 mentioned in 3.1.1.

3. Set P5.02=43 and then switch on S2 (or set P15.01=0) to enable the PV voltage reference.

4. Observe the bus voltage and set P15.02 to ensure the value is less than the bus voltage during operation. The bigger the value is, the bigger the water yield is. It is recommended to use the voltage value which is 20~30V less than the bus voltage in normal operation.

5. Switch off Q1 and S2 and switch on Q2 to switch to PV power supply.

Note: If there is no diode protection at the bus input, Q2 and Q1 can not be switched on at the same time, otherwise, damage may occur to the battery board.

4 Fault instruction

4.1 Common faults and solutions

| Fault code | Fault type | Possible cause | Solutions |
|------------|--|---|---|
| Out1 | IGBT Ph-U fault | 1. The acceleration is too fast. | 1. Increase Acc time. 2. Change the power unit. 3. Check the driving wires. 4. Inspect external equipment and eliminate interference. |
| Out2 | IGBT Ph-V fault | | |
| Out3 | IGBT Ph-W fault | 2. IGBT module fault. 3. The connection of the driving wires is not good, 4. Grounding is not properly. | |
| OC1 | Over-current when acceleration | 1. The acceleration or deceleration is too fast. | 1. Increase the ACC time 2. Check the input power 3. Select the inverter with a larger power 4. Check if the load is short circuited (the grounding short circuited or the wire short circuited) or the rotation is not smooth. 5. Check the output configuration. 6. Check if there is strong interference. |
| OC2 | Over-current when deceleration | 2. The voltage of the grid is too low. | |
| OC3 | Over-current when constant speed running | 3. The power of the inverter is too low. 4. The load transients or is abnormal. 5. The grounding is short circuited or the output is phase loss. 6. There is strong external interference. | |
| OV1 | Over-voltage when acceleration | 1. The input voltage is abnormal. | 1. Check the input power 2. Check if the DEC time of the load is too short or the inverter starts during the |
| OV2 | Over-voltage when deceleration | 2. There is large energy feedback. | |

| Fault code | Fault type | Possible cause | Solutions |
|-------------------|--|---|---|
| OV3 | Over-voltage when constant speed running | | rotation of the motor or it needs to increase the energy consumption components. |
| UV | DC bus Under-voltage | The voltage of the power supply is too low. | Check the input power of the supply line |
| OL1 | Motor overload | <ol style="list-style-type: none"> 1. The voltage of the power supply is too low. 2. The motor setting rated current is incorrect. 3. The motor stall or load transients is too strong. | <ol style="list-style-type: none"> 1. Check the power of the supply line 2. Reset the rated current of the motor 3. Check the load and adjust the torque lift |
| OL2 | Inverter overload | <ol style="list-style-type: none"> 1. The acceleration is too fast 2. Reset the rotating motor 3. The voltage of the power supply is too low. 4. The load is too heavy. 5. Close loop vector control, reverse direction of the code panel and long low-speed operation | <ol style="list-style-type: none"> 1. Increase the ACC time 2. Avoid the restarting after stopping. 3. Check the power of the supply line 4. Select an inverter with bigger power. 5. Select a proper motor. |
| OL3 | Electrical overload | The inverter will report overload pre-alarm according to the set value. | Check the load and the overload pre-alarm point. |
| SPI | Input phase loss | Phase loss or fluctuation of input R,S,T | <ol style="list-style-type: none"> 1. Check input power 2. Check installation distribution |

| Fault code | Fault type | Possible cause | Solutions |
|------------|---------------------|---|--|
| SPO | Output phase loss | U,V,W phase loss input(or serious asymmetrical three phase of the load) | <ol style="list-style-type: none"> 1. Check the output distribution 2. Check the motor and cable |
| OH2 | IGBT overheat | <ol style="list-style-type: none"> 1. Air duct jam or fan damage 2. Ambient temperature is too high. 3. The time of overload running is too long. | <ol style="list-style-type: none"> 1. Refer to the overcurrent solution 2. Redistribute dredge the wind channel or change the fan 3. Low the ambient temperature 4. Check and reconnect 5. Change the power 6. Change the power unit 7. Change the main control panel |
| OH1 | Rectify overheat | | |
| EF | External fault | SI external fault input terminals action | Check the external device input |
| CE | Communication error | <ol style="list-style-type: none"> 1. The baud rate setting is incorrect. 2. Fault occurs to the communication wiring. 3. The communication address is wrong. 4. There is strong interference to the communication. | <ol style="list-style-type: none"> 1. Set proper baud rate 2. Check the communication connection distribution 3. Set proper communication address. 4. Chang or replace the connection distribution or improve the anti-interference capability. |

| Fault code | Fault type | Possible cause | Solutions |
|------------|-------------------------|--|---|
| ItE | Current detection fault | 1. The connection of the control board is not good 2. Assistant power is bad 3. Hoare components is broken 4. The modifying circuit is abnormal. | 1. Check the connector and repatch 2. Change the Hoare 3. Change the main control panel |
| tE | Autotuning fault | 1. The motor capacity does not comply with the inverter capability 2. The rated parameter of the motor does not set correctly. 3. The offset between the parameters from autotune and the standard parameter is huge 4. Autotune overtime | 1. Change the inverter mode 2. Set the rated parameter according to the motor name plate 3. Empty the motor load. 4. Check the motor connection and set the parameter. 5. Check if the upper limit frequency is above 2/3 of the rated frequency. |
| EEP | EEPROM fault | 1. Error of controlling the write and read of the parameters 2. Damage to EEPROM | 1. Press STOP/RST to reset 2. Change the main control panel |
| PIDE | PID feedback fault | 1. PID feedback offline 2. PID feedback source disappear | 1. Check the PID feedback signal 2. Check the PID feedback source |

| Fault code | Fault type | Possible cause | Solutions |
|------------|----------------------------|--|---|
| bCE | Braking unit fault | 1. Braking circuit fault or damage to the braking pipes 2. The external braking resistor is not sufficient | 1. Check the braking unit and , change new braking pipe 2. Increase the braking resistor |
| ETH1 | Grounding shortcut fault 1 | 1. The output of the inverter is short circuited with the ground. 2. There is fault in the current detection circuit. | 1. Check if the connection of the motor is normal or not 2. Change the Hoare 3. Change the main control panel |
| ETH2 | Grounding shortcut fault 2 | 1. The output of the inverter is short circuited with the ground. 2. There is fault in the current detection circuit. | 1. Check if the connection of the motor is normal or not 2. Change the Hoare 3. Change the main control panel |
| dEu | Velocity deviation fault | 1. The load is too heavy or stalled. | 1. Check the load and ensure it is normal. Increase the detection time. 2. Check whether the control parameters are normal. |
| STo | Maladjustment fault | 1. The control parameters of the synchronous motors not set properly. 2. The autoturn parameter is not right. 3. The inverter is not connected to the motor. | 1. Check the load and ensure it is normal. 2. Check whether the control parameter is set properly or not. 3. Increase the maladjustment detection time. |

| Fault code | Fault type | Possible cause | Solutions |
|-------------------|-------------------------------|--|---|
| END | Time reach of factory setting | 1. The actual running time of the inverter is above the internal setting running time. | 1. Ask for the supplier and adjust the setting running time. |
| LL | Electronic underload fault | 1. The inverter will report the underload pre-alarm according to the set value. | 1. Check the load and the underload pre-alarm point. |
| tSF | Hydraulic probe damage | 1. Hydraulic probe damage and the feedback signal wire are not connected well | 1. Check the wiring and change the probe |
| A-LS | Weak light pre-warning | The output frequency is lower than or equal to the lower limit of PI output frequency and keep to reach to the weak light delay time | 1. Check the lower limit of PI output and the setting value of delay time |
| A-LL | Underload pre-warning | 1. The water pumps runs at a small load and the operation time reaches the set time | 1. Check the water level of the resource and the pre-warning point of underload |
| A-tF | Full-water pre-warning | 1. The feedbacked water level is lower than the threshold and keep it for a certain time | 1. Check the pre-warning point of the water level |

Table: recommended solar modules

| Inverter model | Max DC input current (A) | Open-circuit voltage degree of solar module | | | | | | | | | | | | | |
|---------------------|--------------------------|---|----------------------|-------------------|----------------------|-------------------|----------------------|-------------------|----------------------|-------------------|----------------------|-------------------|----------------------|-----|------|
| | | 20±3V | | 30±3V | | 36±3V | | 42±3V | | | | | | | |
| | | Module power ±5Wp | Modules per string * | Module power ±5Wp | Modules per string * | Module power ±5Wp | Modules per string * | Module power ±5Wp | Modules per string * | Module power ±5Wp | Modules per string * | Module power ±5Wp | Modules per string * | | |
| GD100-01-0R7 G-4 | 4.2 | 30 | 29*1 | - | - | - | - | - | - | - | - | - | - | - | - |
| GD100-01-1R5 G-4 | 6.1 | 60 | 30*1 | - | - | - | - | - | - | - | - | - | - | - | - |
| GD100-01-2R2 G-4 | 7.1 | 90 | 30*1 | - | - | 145 | 18*1 | 175 | 15*1 | - | - | - | - | - | - |
| GD100-01-004 G-4 | 16.5 | 85 | 28*2 | 220 | 22*1 | 140 | 17*2 | 160 | 15*2 | - | - | - | - | - | - |
| GD100-01-5R5 G-4 | 23.9 | - | - | - | - | 195 | 17*2 | 220 | 15*2 | - | - | - | - | - | - |
| GD100-01-7R5 G-4 | 30.6 | - | - | 215 | 21*2 | 175 | 17*3 | 200 | 15*3 | 300 | 15*2 | 15*2 | 15*3 | 300 | 15*2 |
| GD100-01-011 G-4 | 39.2 | - | - | 200 | 22*3 | 195 | 17*4 | 220 | 15*4 | - | - | - | 15*4 | - | - |
| GD100-01-015 G-4 | 49 | - | - | 205 | 22*4 | 200 | 18*5 | 240 | 15*5 | 300 | 15*4 | 15*5 | 15*5 | 300 | 15*4 |



Service line:86-755-86312859

Website:www.invt.com

SHENZHEN INVT ELECTRIC CO., LTD.

No. 4 Building, Gaofa Scientific Industrial Park,
Longjing, Nanshan District, Shenzhen, China

Industrial Automation: ■ Frequency Inverter ■ Servo & Motion Control ■ Motor & Electric Spindle ■ PLC
■ HMI ■ Intelligent Elevator Control System ■ Traction Drive

Electric Power: ■ SVG ■ Solar Inverter ■ UPS ■ Online Energy Management System



66001-00186

INVT Copyright.

Information may be subject to change without notice during product improving.

201405(V1.2)